

# Universal Defender® Roll #GRB150M - 30" x 150', 1 roll/package



General-purpose SonicBonded mat for overspray and everyday use.

- Abrasion-resistant top layer gives rolls strength for everyday cleanup jobs
- Perfect for medium-duty industrial, maintenance and general applications
- Quickly absorbs leaks, spills and overspray to keep floors dry
- Perforations allow you to tear rolls into different sizes based on your application
- Universal absorbency means one product for multiple liquids
- Rolls are ideal for covering large areas

## **GRB150M Specifications**

**Dimensions:** 30" W x 150' L

**Shipping** 15" W x 30" L x 15" H

Dimensions:

Sold as: 1 roll per package

Color: Gray

Composition: Polypropylene

Absorbency: Up to 46.1 gal. per package

Weight: 20.4 lbs.

# per Pallet: 21

Basis Weight: MediumWeight

Incinerable: Yes Ship Class: 175

## **Metric Equivalent Specifications**

**Dimensions:** 76.2cm W x 46m L

**Shipping** 38.1cm W x 76.2cm L x 38.1cm H

**Dimensions:** 

**Absorbency:** Up to 174.5 L per package

Weight: 9.3 kg



Online: spilltech.com 1

Phone: 1-800-228-3877 (N.Am.) 1-770-475-3877 (Other) Fax: 1-800-872-3764 (N.Am.) 1-770-410-1812 (Other) Email: sales@spilltech.com

### **GRB150M Technical Information**

#### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

#### **Regulations and Compliance:**

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

#### **Technical Documents:**

(Available at spilltech.com)
Product Data Sheet (PDS)
Safety Data Sheet (SDS)

Chemical Compatibility (CCG)



Phone: 1-800-228-3877 (N.Am.) 1-770-475-3877 (Other) Fax: 1-800-872-3764 (N.Am.) 1-770-410-1812 (Other)

Email: sales@spilltech.com