

# Oil-Only 20-Gallon OverPack Salvage Drum Spill Kit #SPKO-20 - Absorbs up to 15.2 Gallons



Be prepared for fast response with a SpillTech® Oil-Only OverPack Salvage Drum Spill Kit!

## **SPKO-20 Specifications**

**Dimensions:** ext. dia. 23" x 19.5" H **Shipping** 23" W x 23" L x 19" H

**Dimensions:** 

Sold as: 1 per package

**Absorbency:** Up to 15.2 gal. per package

Weight: 22.53 lbs.

# per Pallet: 16
Incinerable: No
Ship Class: 175

**Includes:** 25 - 15" x 19" White Oil-Only

HeavyWeight SonicBonded Pads

(WPB100H)

4 - 3" x 4' White Oil-Only Sorbent

Socks (WSO430)

2 - 18" x 18" White Oil-Only Sorbent

Pillows (WPIL1818)

4 - 18" X 30" Yellow Disposal Bags &

Ties (A-DISPBAG)

1 - Pair Nitrile Gloves (A-GLV-NIT)

1 - Safety Goggles (A-GOG)

1 - 3" x 5" Vinyl Spill Kit Label (A-

KITLABEL)

1 - 23" x 19" Yellow 20-Gallon OverPack (1H2/X75/S) (A20OVER) 6 - 6" x 2" TamperProof Seals (A-

SEAL)

# **Metric Equivalent Specifications**

**Dimensions:** ext. dia. 58cm x 50cm H **Shipping** 58cm W x 58cm L x 48cm H

**Dimensions:** 

**Absorbency:** Up to 57.5 L per package

Weight: 10.2 kg



Phone: 1-800-228-3877 (N.Am.) 1-770-475-3877 (Other) Fax: 1-800-872-3764 (N.Am.) 1-770-410-1812 (Other)

Email: sales@spilltech.com

## **SPKO-20 Technical Information**

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

#### **Regulations and Compliance:**

49 CFR 173.3(c)(1) - If a container of hazardous waste is damaged or leaking, it can be placed in a compatible salvage drum that meets UN criteria for shipping

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

33 CFR 154.1047(c)(2) - Concerning navigation and navigable waters, a facility which handles, stores or transports Group V petroleum oils must identify response plan resources such as containment booms and other methods.

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

#### **Technical Documents:**

(Available at spilltech.com)

Product Data Sheet (PDS)

