

Chemical Compatibility Chart

Maximizer Universal Cellulose Mat

NOTICE:

This report is offered as a guide and was developed from information which, to the best of SpillTech's knowledge, was reliable and accurate. Due to variables and conditions of application beyond SpillTech's control, none of the data shown in this guide is to be construed as a guarantee, expressed or implied. SpillTech assumes no responsibility, obligation, or liability in conjunction with the use or misuse of the information.

ATTENTION:

Due to variables and conditions beyond our control, SpillTech cannot guarantee that this product will absorb to your satisfaction. To ensure effectiveness and your safety, we recommend that you conduct compatibility and absorption testing of your chemicals with these products prior to purchase. If you have any questions or need samples to test, please call us toll free at 1-800-228-3877

Chemical Name	Chemical Class	Rating
Acetone	Ketones	Good
Acetonitrile	Nitriles	Good
Ammonium Hydroxide	Inorganic Base	Not Recommended
Anhydrous Ammonia	Inorganic Base	Good
B100 Bio Diesel Fuel	Aromatic Hydrocarbons	Good
Barium Salts	Barium Compounds	Good
Benzyl Alcohol	Hydroxylic Compounds	Good
Bleach Solution	Inorganic Base	Good
Boric Acid	Inorganic Acids	Not Recommended
Carbon Tetrachloride	Halogen Compounds	Good
Chloroform	Halogen Compounds	Good
Cotton Seed Oil	Oil - Vegetable	Good
Cupric Chloride	Copper compounds	Good
Cyclohexanone	Ketones	Good
Dichloromethane	Halogen Compounds	Good
Diesel Fuel	Aromatic Hydrocarbons	Good
Diethylamine	Amines	Good
E85 Gasoline	Aromatic Hydrocarbons	Good
Ethyl Acetate	Carboxylic Esters	Good
Formaldehyde	Aldehydes	Good
Gasoline	Aromatic Hydrocarbons	Good
Hexane	Aliphatic Hydrocarbons	Good
Hydrazine, Anhydrous	Hydrazine	Not Recommended
Hydrochloric Acid (37%)	Inorganic Acids	Not Recommended
Hydrofluoric Acid (48%)	Inorganic Acids	Not Recommended
Hydrogen Peroxide (30%)	Peroxides	Good
Isopropanol	Hydroxylic Compounds	Good
Jet Fuel (JP-5)	Hydrocarbons	Good



Chemical Compatibility Chart

Maximizer Universal Cellulose Mat (cont.)

Chemical Name	Chemical Class	Rating
Kerosene	Hydrocarbons	Good
Lacquer Thinner	Hydrocarbons	Good
Linseed Oil	Oil - Vegetable	Good
Methanol	Hydroxylic Compounds	Good
Methyl Ethyl Ketone	Ketones	Good
Mineral Oil	Alicyclic Hydrocarbons	Good
Mineral Spirits	Hydrocarbons	Good
Naphtha	Hydrocarbons	Good
Nitric Acid (70%)	Inorganic Acids	Not Recommended
Perchloroethylene	Halogen Compounds	Good
Potassium Hydroxide (50%)	Inorganic Bases	Not Recommended
Propylene Glycol	Hydroxylic Compounds	Good
Sodium Hydroxide (20%)	Inorganic Bases	Not Recommended
Sodium Hydroxide (30%)	Inorganic Bases	Not Recommended
Sodium Hydroxide (40%)	Inorganic Bases	Not Recommended
Sodium Hydroxide (50%)	Inorganic Bases	Not Recommended
Sodium Hydrochlorite	Inorganic Bases	Good
Sulfuric Acid (50%)	Inorganic Acids	Not Recommended
Sulfuric Acid (98%)	Inorganic Acids	Not Recommended
Tetrachloroethylene	Halogen Compounds	Good
Thionyl Chloride	Chloride Compounds	Good
Toluene	Aromatic Hydrocarbons	Good
1, 1, 1 - Trichloroethane	Halogen Compounds	Good
Trichloroethylene	Halogen Compounds	Good
Turpentine	Hydrocarbons	Good
Water	Misc.	Good