

Bladder Spill Containment Deck #BLADDER1 - 26" x 30.5" x 5.75", 1/package



Hidden containment bladder automatically unfurls to capture large spills or drum leaks.

- NOTE: The Item number for this product has recently changed from ULT1320 to BLADDER1. Please make a note of it.
- The first and only low-profile, single-drum containment unit that helps you meet EPA and UFC Containment Regulations
- Compact footprint saves valuable floor space; perfect for single-drum waste collection
- Small spills and leaks are captured in the sump
- Large spills and leaks flow into the bladder through a bulkhead fitting; protective trap door opens automatically to allow bladder to unfurl and fill up
- Rugged, double-layer polyethylene bladder withstands wear and tear

BLADDER1 Specifications

Dimensions:	30.5" W x 26" L x 5.75" H
Shipping Dimensions:	27" W x 35" L x 7" H
Sold as:	1 per package
Color:	Yellow
Composition:	100% Polyethylene
Load Capacity UDL:	1500 lbs. per package
Sump Capacity:	66 gal. per package
Weight:	27 lbs.
# per Pallet:	20
Incinerable:	No
Ship Class:	100

Metric Equivalent Specifications

Dimensions:	77.5cm W x 66cm L x 14.6cm H
Shipping Dimensions:	68.6cm W x 88.9cm L x 17.8cm H
Sold as:	1 per package
Color:	Yellow
Composition:	100% Polyethylene
Load Capacity UDL:	680.4 kg per package
Sump Capacity:	249.8 L per package
Weight:	12.2 kg

BLADDER1 Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com