

550 Containment Sump #SUMP550-ND - Without Drain 1/package



Sump offers secondary containment for 500- and 550-gallon tanks.

- Eliminate costly spills while storing fuels, oils and other hazardous liquids
- 100% polyethylene construction will not rust or corrode; provides superior chemical and weather resistance
- Offers the best protection for non-monitored containment sites
- Also available with drain plug (SUMP550-WD) to let you easily remove collected liquid

SUMP550-ND Specifications

Dimensions:	62.25" W x 87" L x 32.75" H
Shipping Dimensions:	60" W x 89" L x 34" H
Sold as:	1 per package
Color:	Black
Composition:	100% Polyethylene
Sump Capacity:	605 gal. per package
Weight:	108 lbs.
# per Pallet:	6
Incinerable:	No
Ship Class:	300

Metric Equivalent Specifications

Dimensions:	158.1cm W x 2.2m L x 83.2cm H
Shipping Dimensions:	152.4cm W x 2.3m L x 86.4cm H
Sump Capacity:	2289.9 L per package
Weight:	49 kg

SUMP550-ND Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

40 CFR 122.26 - Facilities must have a detailed plan in place to prevent illegal discharge of pollutants into waterways.

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com