

Build Your Own Berm® Straight Section #BYOB-2S - 15' x 5.5" x 2", 1/package



Build your own barrier around equipment or storage, indoors or out.

- Semi-permanent, highly visible berm is customizable to your desired size and shape
- Vinyl covered foam barrier resists oils, coolants and most chemicals
- Recovers its shape under foot traffic or light, wheeled equipment
- Easy to cut with utility knife
- Secure to smooth surfaces with Sili-Thane (BYOB-SEAL) sealant or join seams with Industrial Strength Vinyl Cement (BYOB-CEMENT)
- Inexpensive and easy-to-install containment alternative to cement curbs or angle iron
- Simple removal with flat-bladed shovel
- Ideal for leak-prone areas like battery charging stations or machinery

BYOB-2S Specifications

Dimensions:	5.5" W x 15' L x 2" H
Shipping Dimensions:	30.33" W x 30.33" L x 6.75" H
Sold as:	1 per package
Color:	Yellow
Composition:	18oz All-Vinyl Covering with Open-Cell Foam Interior
Weight:	6 lbs.
# per Pallet:	24
Incinerable:	No
Ship Class:	300

Metric Equivalent Specifications

Dimensions:	14cm W x 4.6m L x 5.1cm H
Shipping Dimensions:	77cm W x 77cm L x 17cm H
Dimensions:	
Weight:	2.7 kg

BYOB-2S Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

40 CFR 122.26 - Facilities must have a detailed plan in place to prevent illegal discharge of pollutants into waterways.

40 CFR 112.7(c)(1) - Facilities must have "appropriate containment and/or diversionary structures to prevent discharge oil from reaching a navigable water course."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Chemical Compatibility (CCG)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com