

## 2 Drum Roll Top Hardcover With Drain #HARDTOP2-WD - With Drain 1/package



Store hazardous drums safely outdoors with pumps and funnels in place!

- NOTE: The Item number for this product has recently changed from ULT9613 to HARDTOP2-WD. Please make a note of it.
- Extra headspace easily accommodates rotary drum pumps and large conical funnels
- Low-profile containment pallet positions drum tops at a safe, convenient level to pour wastes into funnels or use drum pumps
- 100% polyethylene construction will not rust or corrode
- Roll-top covers can be easily lifted from waist height to access drum tops; no need to reach near ground level
- Swing out lower doors provide full access to drums for loading and unloading
- Drain plug lets you empty sump without relocating stored containers
- Lockable with a standard padlock; safely lifted by forklift with drums in place
- Optional loading ramp (HTRAMP) with non-slip surface stores neatly inside when not in use — even when loaded with two 55-gallon drums



**SpillTech**

Online:  
[spilltech.com](https://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)

## HARDTOP2-WD Specifications

<b>Dimensions:</b>	41.25" W x 67.25" L x 74" H
<b>Shipping</b>	48" W x 72" L x 81" H
<b>Dimensions:</b>	
<b>Sold as:</b>	1 per package
<b>Color:</b>	Yellow
<b>Composition:</b>	100% Polyethylene
<b>Load Capacity UDL:</b>	4500 lbs. per package
<b>Sump Capacity:</b>	66 gal. per package
<b>Weight:</b>	355 lbs.
<b># per Pallet:</b>	1
<b>Incinerable:</b>	No
<b>Ship Class:</b>	250

## Metric Equivalent Specifications

<b>Dimensions:</b>	105cm W x 171cm L x 188cm H
<b>Shipping</b>	122cm W x 183cm L x 206cm H
<b>Dimensions:</b>	
<b>Load Capacity UDL:</b>	2041.2 kg per package
<b>Sump Capacity:</b>	249.8 L per package
<b>Weight:</b>	161 kg

## HARDTOP2-WD Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

40 CFR 122.26 - Facilities must have a detailed plan in place to prevent illegal discharge of pollutants into waterways.

### Technical Documents:

(Available at [spilltech.com](https://spilltech.com))

Product Data Sheet (PDS)



**SpillTech**

Online:  
[spilltech.com](https://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)