

Ultra-Oil Stain Remover®

Completely remove stains from treated or untreated concrete, asphalt or brick



Apply



Dry



Sweep Away the Stain

General Reminders:

Always test a small area before use.

Shake well.

Do not use on wet surfaces.

For best performance, use above 60°F (16°C) and provide maximum ventilation.

Application:

1. Scrape off buildup and sweep area.
2. Apply to stain, extending one inch beyond perimeter. For initial treatment, no scrubbing is required.
3. Allow to dry completely to powder (5-8 hours or longer depending on temperature, humidity, and ventilation).
4. Sweep up. If area still appears dark, provide adequate ventilation and allow moisture to evaporate.
5. If stain remains, reapply, scrub with stiff-bristled brush, and repeat steps 3 and 4.

When removing stains from asphalt, a second application will most likely be needed.

ATTENTION: Prior use of other cleaners may inhibit performance.

Coverage:

A 32oz bottle treats an area approximately 6 - 7 square feet. A 16oz bottle treats an area approximately 1½ - 3 square feet.

CAUTION:

Provide maximum ventilation during use.

Do not mix with other chemicals.

KEEP OUT OF REACH OF CHILDREN AND PETS.

Avoid contact with grass or plants.

Avoid inhalation of dust when sweeping.

Avoid eye and skin contact.

Eye Contact:

Flood eyes repeatedly with water and call a physician.

If Swallowed:

Do not induce vomiting.

Drink a glass of water and call physician immediately.

