

IBC Spill Pallet With Drain #IBC-WD - With Drain 1/package



Spill Pallet Plus gives you economical and portable containment for IBCs.

- NOTE: The Item number for this product has recently changed from ULT1158 to IBC-WD. Please make a note of it.
- Low height and large deck make placing, handling and dispensing from IBCs safe and convenient
- All-polyethylene construction offers excellent chemical resistance; will not rust or corrode
- Forkliftable for easy relocation
- Small footprint requires minimal floor space
- Drain plug lets you empty sump without relocating stored containers
- Five inner support columns help Deck easily hold a fully loaded IBC; components can be removed for cleaning
- Optional Bucket Shelf (IBCSHELF) catches small leaks and spills while dispensing; larger spills are channeled into the sump through a bulkhead fitting

IBC-WD Specifications

Dimensions:	62" W x 62" L x 28" H
Shipping Dimensions:	62" W x 64" L x 28" H
Sold as:	1 per package
Color:	Yellow
Composition:	100% Polyethylene
Load Capacity UDL:	8500 lbs. per package
Sump Capacity:	360 gal. per package
Weight:	324 lbs.
# per Pallet:	1
Incinerable:	No
Ship Class:	175

Metric Equivalent Specifications

Dimensions:	157.5cm W x 157.5cm L x 71.1cm H
Shipping Dimensions:	157.5cm W x 162.6cm L x 71.1cm H
Load Capacity UDL:	3855.6 kg per package
Sump Capacity:	1362.6 L per package
Weight:	147 kg

IBC-WD Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com