

30-Gallon OverPack Salvage Drum #A30OVER - 23" dia x 30", 1 each/package



Stock a SpillTech® OverPack with sorbents for emergency spill response, or use it as a salvage drum to ship damaged containers or hazardous waste.

- Tough UN Rated overpack is built to withstand rough handling. Guaranteed.
- X-rated for Packing Groups I, II and III, so it's ideal for regulated packaging applications, including shipping hazardous waste by land, sea or rail
- Polypropylene material with UV inhibitors is durable, lightweight and chemical-resistant
- Containers are nestable when empty to save storage space
- Designed and proven to withstand the abuse of shipping to help keep hazardous waste safely contained
- Specifically designed and sized for leaking cans, bottles or 5-gallon pails
- Leakproof, twist-on lid is notched so you can easily tighten it with a 2x4 or pole
- Integrated ledges and handles molded into container let you move overpack with a forklift or by hand

A30OVER Specifications

Dimensions:	ext. dia. 23" x 30" H
Shipping	23" W x 30" L x 23" H
Dimensions:	
Sold as:	1 per package
Color:	Yellow
Composition:	Copolymer-polypropylene
Weight:	14.7 lbs.
# per Pallet:	24
Incinerable:	No
UN RATING:	1H2/X70/S
Ship Class:	250

Metric Equivalent Specifications

Dimensions:	ext. dia. 58cm x 76cm H
Shipping	58cm W x 76cm L x 58cm H
Dimensions:	
Weight:	6.7 kg

A30OVER Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(1) - If a container of hazardous waste is damaged or leaking, it can be placed in a compatible salvage drum that meets UN criteria for shipping

49 CFR 173.12(b)(2)(iv) - When labpacking, "Inner packagings...must be surrounded by a chemically compatible absorbent material in sufficient quantity to absorb the total liquid contents."

49 CFR 173.12(b) - A container used for labpacking must be "a UN 1A2 or UN 1B2 metal drum, a UN 1D plywood drum, a UN 1G fiber drum or a UN 1H2 plastic drum tested and marked at least for the Packing Group III performance level for liquids or solids."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Chemical Compatibility (CCG)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com