

## Oil-Only TrackMat Roll #TMAT57 - 57" x 80', 1 roll/package



Help prevent ground contamination with an absorbent mat specially designed for outdoor railroad maintenance.

- Oil-Only TrackMat features a highly-absorbent meltblown core that quickly soaks up and retains oils, lubricants and other petroleum-based liquids. Repels water so absorbent capacity isn't wasted.
- Heavy-duty spunbond top layer adds strength and durability for long-term deployment in almost any weather conditions.
- Thick bottom layer of clear polypropylene prevents liquids from leaching into the ground below.
- Sized to fit between standard railroad tracks.

### TMAT57 Specifications

<b>Dimensions:</b>	57" W x 80' L
<b>Shipping Dimensions:</b>	16" W x 57" L x 16" H
<b>Sold as:</b>	1 roll per package
<b>Color:</b>	Black
<b>Composition:</b>	100% Polypropylene
<b>Absorbency:</b>	Up to 63.2 gal. per package
<b>Absorbency per:</b>	Up to 63.2 gal. per roll
<b>Weight:</b>	46 lbs.
<b># per Pallet:</b>	15
<b>Basis Weight:</b>	HeavyWeight
<b>Incinerable:</b>	Yes
<b>Ship Class:</b>	175

### Metric Equivalent Specifications

<b>Dimensions:</b>	144.8cm W x 24m L
<b>Shipping Dimensions:</b>	40.6cm W x 144.8cm L x 40.6cm H
<b>Absorbency:</b>	Up to 239.2 L per package
<b>Absorbency per:</b>	Up to 239.2 L per roll
<b>Weight:</b>	20.9 kg

## TMAT57 Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### Regulations and Compliance:

40 CFR 122.26 - Facilities must have a detailed plan in place to prevent illegal discharge of pollutants into waterways.

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

### Technical Documents:

(Available at [spilltech.com](http://spilltech.com))

Product Data Sheet (PDS)

Safety Data Sheet (SDS)



**SpillTech**

Online:  
[spilltech.com](http://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)