

## 2-Drum Spill Pallet #ULT2505 - with drain



Store drums and other leak- or spill-prone containers on this Pallet to help you comply with regulations.

- **Low Profile and Heavy Load Capacity:** 2-Drum Pallet has a low profile and can hold up to 1,500 lb.
- **Meets Containment Requirements:** Provides a 66-gallon sump to protect and help keep you in compliance — in the event of a small leak or complete drum failure.
- **Strong, Durable and Long Lasting:** All-polyethylene construction makes this Pallet light-weight and resistant to chemicals. Won't rust or corrode. Black color disguises dirt and wear and tear -- keeps the Pallet looking good.
- **Removable Grate Makes It Easy to Get to the Sump:** Equipped with a polyethylene grate that can be easily removed for quick access to sump area. Drain plug makes it simple to empty.

## ULT2505 Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

### Technical Documents:

(Available at [spilltech.com](http://spilltech.com))

Product Data Sheet (PDS)

Chemical Compatibility (CCG)