

Oil-Only Bilge Boom #WBB318 - 3" x 18" 20/package



Absorb the pollutants that build up in a boat's bilge to avoid potential fines and environmental damage. Oil-Only Bilge Booms repel water but soak up oil, gas and diesel before they can spread into navigable waters.

- Sized to fit into bilges, engine compartments, sumps, tanks and more; attach rope to metal clip to easily deploy and retrieve
- Chemical-resistant poly skin is filled with highly-sorbent poly blend; Booms won't shed or sink, even when saturated with oil
- Poly blend is hydrophobic — repels water (and floats) while only absorbing oils and other hydrocarbons
- Oil stands out on bright white Boom; easy to see saturation level, so you save money by not throwing it away too soon

WBB318 Specifications

Dimensions:	ext. dia. 3" x 18" L
Shipping Dimensions:	17" W x 25.25" L x 12" H
Sold as:	20 per package
Color:	White
Composition:	Poly Blend Filler/Polyester Netting/Metal Hardware
Recycled Content:	97% Post-Industrial Recycled Poly Blend Filler
Absorbency:	Up to 6.25 gal. per package
Absorbency per:	Up to 40 oz.
Weight:	8 lbs.
# per Pallet:	30
Incinerable:	Yes
Ship Class:	175

Metric Equivalent Specifications

Dimensions:	ext. dia. 7.6cm x 45.7cm L
Shipping Dimensions:	43.2cm W x 64.1cm L x 30.5cm H
Absorbency:	Up to 23.7 L per package
Absorbency per:	Up to 1.2 L
Weight:	3.6 kg

WBB318 Technical Information

Warnings & Restrictions:

Color Variance Notice
Color may vary.

Regulations and Compliance:

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 122.26 - Facilities must have a detailed plan in place to prevent illegal discharge of pollutants into waterways.

40 CFR 112.7(c)(1) - Facilities must have "appropriate containment and/or diversionary structures to prevent discharge oil from reaching a navigable water course."

33 CFR 154.1047(c)(2) - Concerning navigation and navigable waters, a facility which handles, stores or transports Group V petroleum oils must identify response plan resources such as containment booms and other methods.

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com