

Ultra-Spill Deck P1 Bladder System® #ULT1320 - 26" x 30.5" x 5.75" 1/package



Hidden containment bladder automatically unfurls to capture large spills or drum leaks.

- The first and only low-profile, single-drum containment unit that helps you meet EPA and UFC Containment Regulations
- Compact footprint saves valuable floor space; perfect for single-drum waste collection
- Small spills and leaks are captured in the sump
- Large spills and leaks flow into the bladder through a bulkhead fitting; protective trap door opens automatically to allow bladder to unfurl and fill up
- Rugged, double-layer polyethylene bladder withstands wear and tear

ULT1320 Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)