

Ultra-550 Containment Sump #ULT2823 - Without Drain 1/package



Sump offers secondary containment for 500- and 550-gallon tanks.

- Eliminate costly spills while storing fuels, oils and other hazardous liquids
- 100% polyethylene construction will not rust or corrode; provides superior chemical and weather resistance
- Offers the best protection for non-monitored containment sites
- Also available with drain plug (ULT2820) to let you easily remove collected liquid

ULT2823 Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

40 CFR 122.26 - Facilities must have a detailed plan in place to prevent illegal discharge of pollutants into waterways.

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)