

Containment Berm - Hurdle Bracket #BERM1212H - 12' x 12' x 1', 1 each/package



Provide large-scale containment that helps meet regulations with this durable, drive-in berm.

- Reinforced Coolguard® fabric resists rips, tears and punctures; highly durable for demanding applications
- Chemical-resistant berm is compatible with acids, water, oils and solvents
- Sidewalls are supported by wide-base hurdle brackets; larger support area offers maximum rigidity and stability
- Great for long-term containment of drums, totes, roll-offs, equipment and vehicles; also ideal for decon stations or response to tank leaks
- Reusable berm can be repaired if damaged; clean, fold and store for future deployment

BERM1212H Specifications

Dimensions:	12' W x 12' L x 1' H
Shipping Dimensions:	40" W x 48" L x 14" H
Sold as:	1 per package
Color:	Black
Composition:	Coolguard® Fabric 36 mil / Aluminum Brackets
Sump Capacity:	1077 gal. per package
Weight:	68 lbs.
# per Pallet:	8
Incinerable:	No
Ship Class:	175

Metric Equivalent Specifications

Dimensions:	3.7m W x 3.7m L x 30.5cm H
Shipping Dimensions:	101.6cm W x 121.9cm L x 35.6cm H
Sump Capacity:	4076.4 L per package
Weight:	30.8 kg

BERM1212H Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

Chemical Compatibility (CCG)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com