

## 4-Drum Steel Pallet #QTX1212 - 50" x 50" x 13", 1 each/package



These 14-gauge galvanized steel containment pallets are the strongest on the market!

- Each pallet has a 250 PSF loading capacity and a 60 gallon sump capacity
- Noncombustible pallets meet spill control and containment requirements and regulations
- Pallets will not melt under fire exposure or fail from normal material handling activities
- 100% leak-free tested
- Removable grating

### QTX1212 Technical Information

#### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

#### Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

40 CFR 122.26 - Facilities must have a detailed plan in place to prevent illegal discharge of pollutants into waterways.

40 CFR 112.7(c)(1) - Facilities must have "appropriate containment and/or diversionary structures to prevent discharge oil from reaching a navigable water course."

#### Technical Documents:

(Available at [spilltech.com](http://spilltech.com))

Product Data Sheet (PDS)