

Foam Wall Coolguard Containment Berm #BERM1212FC - 12' x 12' x 4", 1 each/package



Foam berms offer drive-in capability and outstanding containment capacity.

- Soft foam sidewalls allow you to roll in equipment or vehicles with minimal set up
- Capture and contain leaks, drips or spills from drums, tanks, totes, equipment or vehicles
- Use for frac tanks, vehicle washdown, refueling areas and secondary containment areas
- Low profile 4" walls compress under equipment then bounce back into shape
- Simply unfold and use; No setup needed
- Easy cleaning and storage
- Designed for repeated use
- Made with 36mil Coolguard, the preferred material for rugged jobs because it's the most durable and has the highest UV resistance

BERM1212FC Specifications

| | |
|-----------------------------|--|
| Dimensions: | 12' W x 12' L x 4" H |
| Shipping Dimensions: | 45" W x 48" L x 50" H |
| Sold as: | 1 per package |
| Color: | Black |
| Composition: | Coolguard® Fabric 36 mil / Built in Foam Sidewalls |
| Sump Capacity: | 359 gal. per package |
| Weight: | 90 lbs. |
| # per Pallet: | 8 |
| Incinerable: | No |
| Ship Class: | 300 |

Metric Equivalent Specifications

| | |
|-----------------------------|---------------------------------|
| Dimensions: | 3.7m W x 3.7m L x 10.2cm H |
| Shipping Dimensions: | 114.3cm W x 121.9cm L x 127cm H |
| Sump Capacity: | 1358.8 L per package |
| Weight: | 40.8 kg |

BERM1212FC Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

Chemical Compatibility (CCG)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com