

## Foam Wall Coolguard Containment Berm #BERM1250FC - 12' x 50' x 4", 1 each/package



Foam berms offer drive-in capability and outstanding containment capacity.

- Soft foam sidewalls allow you to roll in equipment or vehicles with minimal set up
- Capture and contain leaks, drips or spills from drums, tanks, totes, equipment or vehicles
- Use for frac tanks, vehicle washdown, refueling areas and secondary containment areas
- Low profile 4" walls compress under equipment then bounce back into shape
- Simply unfold and use; No setup needed
- Easy cleaning and storage
- Designed for repeated use
- Made with 36mil Coolguard, the preferred material for rugged jobs because it's the most durable and has the highest UV resistance

### BERM1250FC Specifications

<b>Dimensions:</b>	50' W x 12' L x 4" H
<b>Shipping Dimensions:</b>	48" W x 72" L x 75" H
<b>Sold as:</b>	1 per package
<b>Color:</b>	Black
<b>Composition:</b>	Coolguard® Fabric 36 mil / Built in Foam Sidewalls
<b>Sump Capacity:</b>	1496 gal. per package
<b>Weight:</b>	230 lbs.
<b># per Pallet:</b>	2
<b>Incinerable:</b>	No
<b>Ship Class:</b>	300

### Metric Equivalent Specifications

<b>Dimensions:</b>	15m W x 3.7m L x 10.2cm H
<b>Shipping Dimensions:</b>	121.9cm W x 182.9cm L x 190.5cm H
<b>Sump Capacity:</b>	5662.4 L per package
<b>Weight:</b>	104.3 kg

## BERM1250FC Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

### Technical Documents:

(Available at [spilltech.com](http://spilltech.com))

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

Chemical Compatibility (CCG)



**SpillTech**

Online:  
[spilltech.com](http://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)