

Foam Wall Economy Containment Berm #BERM1250FE - 12' x 50' x 4", 1 each/package



Foam berms offer drive-in capability and outstanding containment capacity.

- Soft foam sidewalls allow you to roll in equipment or vehicles with minimal set up
- Capture and contain leaks, drips or spills from drums, tanks, totes, equipment or vehicles
- Use for frac tanks, vehicle washdown, refueling areas and secondary containment areas
- Low profile 4" walls compress under equipment then bounce back into shape
- Simply unfold and use; No setup needed
- Easy cleaning and storage
- Designed for repeated use
- Made with 36mil Reinforced Polyethylene (RPE), which is lightweight and highly chemically compatible

BERM1250FE Specifications

Dimensions:	50' W x 12' L x 4" H
Shipping Dimensions:	48" W x 72" L x 75" H
Sold as:	1 per package
Color:	Black
Composition:	36mil Reinforced Polyethylene/Built in Foam Sidewalls
Sump Capacity:	1496 gal. per package
Weight:	200 lbs.
# per Pallet:	2
Incinerable:	No
Ship Class:	300

Metric Equivalent Specifications

Dimensions:	15.2m W x 3.7m L x 10cm H
Shipping Dimensions:	122cm W x 183cm L x 191cm H
Sump Capacity:	5662.4 L per package
Weight:	90.7 kg

BERM1250FE Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com