

## IBC Spill Pallet With Drain #IBC-WD - With Drain 1/package



Spill Pallet Plus gives you economical and portable containment for IBCs.

- NOTE: The Item number for this product has recently changed from ULT1158 to IBC-WD. Please make a note of it.
- Low height and large deck make placing, handling and dispensing from IBCs safe and convenient
- All-polyethylene construction offers excellent chemical resistance; will not rust or corrode
- Forkliftable for easy relocation
- Small footprint requires minimal floor space
- Drain plug lets you empty sump without relocating stored containers
- Five inner support columns help Deck easily hold a fully loaded IBC; components can be removed for cleaning
- Optional Bucket Shelf (IBCSHELF) catches small leaks and spills while dispensing; larger spills are channeled into the sump through a bulkhead fitting

### IBC-WD Specifications

<b>Dimensions:</b>	62" W x 62" L x 28" H
<b>Shipping Dimensions:</b>	62" W x 64" L x 28" H
<b>Sold as:</b>	1 per package
<b>Color:</b>	Yellow
<b>Composition:</b>	100% Polyethylene
<b>Load Capacity UDL:</b>	8500 lbs. per package
<b>Sump Capacity:</b>	360 gal. per package
<b>Weight:</b>	324 lbs.
<b># per Pallet:</b>	1
<b>Incinerable:</b>	No
<b>Ship Class:</b>	175

### Metric Equivalent Specifications

<b>Dimensions:</b>	157.5cm W x 157.5cm L x 71.1cm H
<b>Shipping Dimensions:</b>	157.5cm W x 162.6cm L x 71.1cm H
<b>Dimensions:</b>	
<b>Load Capacity UDL:</b>	3855.6 kg per package
<b>Sump Capacity:</b>	1362.6 L per package
<b>Weight:</b>	147 kg

## IBC-WD Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### Regulations and Compliance:

40 CFR 264.175 - Hazardous waste containment systems must be free of structural cracks or gaps; designed to keep spilled liquids from remaining in contact with the container; prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers or the volume of the largest container, whichever is greater." For example, four 55-gallon drums require secondary containment of 55 gallons.

### Technical Documents:

(Available at [spilltech.com](http://spilltech.com))

Product Data Sheet (PDS)



**SpillTech**

Online:  
[spilltech.com](http://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)