

Universal FineFiber Pads #GPF1113H - 11" x 13", 100 pads/package



Universal FineFiber Mat Pads grip the floor and absorb oils, coolants, solvents and water where you walk to keep floors dry and safe.

- **Grips the Floor for Safety:** Top and bottom layers of FineFiber are built of densely-woven, small-diameter strands of fiber to increase surface area — enabling the Mat to grip the floor and secure it for safer walking. Universal application for oil, coolants, solvents and water.
- **Virtually Indestructible:** FineFiber Mat has a layer of MeltBlown polypropylene ultrasonically sandwiched between two FineFiber layers. Sonic-bonded "Dimples" add fast-wicking power and strength. 3-ply construction gives Mat durability to resist heavy foot traffic for longer wear and fewer changeouts.
- **High Sorbency Means It Stays on the Job Longer:** Large-diameter MeltBlown polypropylene fibers create a high-loft inner layer that absorbs high volumes of liquid fast. HeavyWeight construction offers the greatest sorbency.
- **Multi-Perforations Save You Money:** Pads are perfed vertically at 7.5". Tear off only what you need — save money!
- **Built for Convenience:** Specially sized for stocking your SpillTech® Spill Kit. Color-coding helps you visually identify the right sorbent for your needs. Gray signifies Universal sorbency.



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com

GPF1113H Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

Chemical Compatibility (CCG)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com