

# Oil-Only 95-Gallon Kit Refill #RSPKO-95 - Absorbs up to 79.7 Gallons



Refill your SpillTech® Oil-Only 95-Gallon Spill Kit to ensure fast response.

# **RSPKO-95 Specifications**

**Metric Equivalent Specifications** 

46cm W x 61cm L x 56cm H

Up to 301.7 L per package

29.6 kg

**Dimensions:** 

Absorbency:

Weight:

**Dimensions:** 18" W x 24" L x 22" H

Sold as: 2 per package

**Absorbency:** Up to 79.7 gal. per package

Weight: 65.29 lbs.

# per Pallet: 10
Incinerable: Yes
Ship Class: 175

Includes: 150 - 15" x 19" White Oil-Only

HeavyWeight SonicBonded Pads

(WPB100H)

12 - 3" x 4' White Oil-Only Sorbent

Socks (WSO430)

6 - 3" x 8' White Oil-Only Sorbent

Socks (WSO815)

7 - 18" x 18" White Oil-Only Sorbent

Pillows (WPIL1818)

3 - 1 lb. Plug & Dike Epoxy Putty (A-

PND)

2 - Pair Nitrile Gloves (A-GLV-NIT)

1 - Safety Goggles (A-GOG)

4 - 30" x 6" x 60" Yellow Disposal

Bags & Ties (A-DISPBAG)

1 - Emergency Response GuideBook

(A-EGB)

1 - 3" x 5" Vinyl Spill Kit Label (A-

KITLABEL)

6 - 6" X 2" TamperProof Seals (A-

SEAL)

Fax: 1-800-872-3764 (N.Am.) 1-770-410-1812 (Other)

Email: sales@spilltech.com

Phone:

1-800-228-3877 (N.Am.)

1-770-475-3877 (Other)

## **RSPKO-95 Technical Information**

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

#### **Regulations and Compliance:**

49 CFR 173.3(c)(1) - If a container of hazardous waste is damaged or leaking, it can be placed in a compatible salvage drum that meets UN criteria for shipping

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

33 CFR 154.1047(c)(2) - Concerning navigation and navigable waters, a facility which handles, stores or transports Group V petroleum oils must identify response plan resources such as containment booms and other methods.

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

#### **Technical Documents:**

(Available at spilltech.com)

Product Data Sheet (PDS)

