


## HazMat FineFiber Pads #YPF1113H - 11" x 13", 100 pads/package



When hazardous liquids spill, use HazMat Sorbents for quick, efficient response. These polypropylene FineFiber Mat Pads soak up acids, bases and unknown fluids fast.

- **The Power of HazMat:** 100% polypropylene Mat quickly absorbs nearly any type of caustic, hazardous or unknown liquid — including acids, bases, solvents and chemicals. Color-coded Safety Yellow for fast identification; know exactly what you're reaching for in an emergency spill situation.
- **Fast-Acting for Quick Response:** Top and bottom layers of FineFiber are built of densely-woven, small-diameter strands of fiber to increase surface area — enabling the Mat to quickly soak up liquids on contact before they can spread. Specially sized for stocking your SpillTech® Spill Kit.
- **High Sorbency:** A random assembly of large-diameter MeltBlown polypropylene fibers creates a high-loft inner layer that absorbs high volumes of liquid fast. HeavyWeight construction offers the greatest sorbency.
- **Virtually Indestructible:** FineFiber Mat has a layer of MeltBlown polypropylene ultrasonically sandwiched between two FineFiber layers. Sonic-bonded "Dimples" add fast-wicking power and strength. 3-ply construction gives Mat durability.
- **Multi-Perforations Save You Money:** Pads are perfed vertically at 7.5". Tear off only what you need — save money!

## YPF1113H Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

### Technical Documents:

(Available at [spilltech.com](https://spilltech.com))

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

Chemical Compatibility (CCG)



Online:  
[spilltech.com](https://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)