

HazMat Tote Spill Kit #SPKHZ-TOTE - Absorbs up to 7.49 Gallons



Be prepared for fast response with a high-visibility SpillTech® HazMat Spill Kit!

- Durable, water-resistant vinyl bag with zipper keeps contents clean and dry
- Packed with a variety of quality SpillTech® HazMat sorbents to handle nearly any type of small caustic, hazardous or unknown spill — including acids, bases, solvents and chemicals
- Bright green kit stands out, even in low light conditions
- Compact design is perfect for use in trucks or other equipment
- Sturdy handles for easy carrying and hanging



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com

SPKHZ-TOTE Specifications

Dimensions:	15" W x 20" L x 4" H
Shipping Dimensions:	15" W x 20" L x 4" H
Sold as:	1 per package
Absorbency:	Up to 7.49 gal. per package
Weight:	5.88 lbs.
# per Pallet:	80
Incinerable:	No
Ship Class:	175
Includes:	20 - 15" X 19" Yellow HazMat HeavyWeight SonicBonded Pads (YPB100H) 2 - 3" x 4' Yellow HazMat Sorbent Socks (YSO430) 2 - 18" X 30" Yellow Disposal Bag & Tie (A-DISP BAG-SM) 1 - Pair Nitrile Gloves (A-GLV-NIT) 1 - Safety Goggles (A-GOG) 1 - 20" X 15" X 4" Green Tote Bag (A-GTOTE)

Metric Equivalent Specifications

Dimensions:	38.1cm W x 50.8cm L x 10.2cm H
Shipping Dimensions:	38.1cm W x 50.8cm L x 10.2cm H
Absorbency:	Up to 28.3 L per package
Weight:	2.7 kg

SPKHZ-TOTE Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

33 CFR 154.1047(c)(2) - Concerning navigation and navigable waters, a facility which handles, stores or transports Group V petroleum oils must identify response plan resources such as containment booms and other methods.

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com