

Universal Forklift Spill Kit #SPKU-LIFT - Absorbs up to 8.3 Gallons



Store this fully stocked spill kit on your forklift for super-fast cleanup of accidental spills.

- Easy access to absorbents and PPE keep your workers and workplace safe in the event of forklift-related accidents like punctured drums, leaking tanks or spilled containers
- Bag attaches securely with hanging straps to the seat or back beam of a fork truck or other type of mobile equipment
- Contains Universal Absorbents to clean up to spills of oils, coolants, solvents and water; also contains PPE
- Bag is durable and weather-resistant with a secure, zipper style closure to protect sorbents inside; reusable and easily replenished

SPKU-LIFT Specifications

Dimensions:	ext. dia. 10" x 22" L
Shipping	20" W x 22" L x 9" H
Dimensions:	
Sold as:	1 per package
Color:	Black
Absorbency:	Up to 8.3 gal. per package
Weight:	7.37 lbs.
# per Pallet:	32
Incinerable:	No
Ship Class:	92.5
Includes:	20 - 15" x 19" Gray Universal HeavyWeight SonicBonded Pads (GPB100H) 3 - 3" x 4' Gray Universal Sorbent Socks (GSO430) 2 - 18" x 30" Yellow Disposal Bag & Tie (A-DISP BAG-SM) 1 - Pair Nitrile Gloves (A-GLV-NIT) 1 - Safety Goggles (A-GOG) 1 - 10" dia x 22" Forklift Bag (A-LIFTBAG)

Metric Equivalent Specifications

Dimensions:	ext. dia. 25cm x 56cm L
Shipping	51cm W x 56cm L x 23cm H
Dimensions:	
Absorbency:	Up to 31.4 L per package
Weight:	3.3 kg

SPKU-LIFT Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

33 CFR 154.1047(c)(2) - Concerning navigation and navigable waters, a facility which handles, stores or transports Group V petroleum oils must identify response plan resources such as containment booms and other methods.

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com